



SAMPLES OF CURRENT MODELS



REFRIGERATORS

WHIRLPOOL: MODEL WRF535SMBM

ISSUES:	COMMENTS:
The lights and control panel illuminate when door is opened.	Required remedy: A Shabbat switch/a piece of tape will disable the lights.
The defrost heater works with an adaptive defrost system.	Issue can be avoided with the use of a timer.
The fridge uses a sensor to detect the temperature which turns on the fan and compressor.	Issue can be avoided with the use of a timer.
The temperature in the refrigerator is regulated by a motorized damper.	Issue can be avoided with the use of a timer.
Ice maker can turn on if ice is removed.	If ice maker bar is put into the up position, it will not make new ice.
The water dispenser on select models may not be used.	

LG: MODEL LMXS30776ST

ISSUES:	COMMENTS:
The lights illuminate and fans stop when door is opened.	The fridge lights can be disabled by placing a magnet over both door hinges. The freezer lights and fans can be disabled by placing a magnet inside the freezer section.
Door alarm will sound if door is left open due to drop in temperature.	The door alarm must be deactivated before Shabbat.
The defrost heater works with an adaptive defrost system.	Issue can be avoided with the use of a timer.
The temperature in the refrigerator is regulated by a motorized damper.	Issue can be avoided with the use of a timer.
Ice maker can turn on if ice is removed.	The ice maker has an on/off toggle switch.
The water dispenser on select models may not be used.	The water dispenser should remain in the child lock position over Shabbat.

FRIGIDAIRE: MODEL FGHN2866PF FRENCH DOOR REFRIGERATOR

ISSUES:	COMMENTS:
The lights illuminate when door is opened.	Sabbath mode will disable the lights alarm as well as the ice maker.
The defrost heater works with an adaptive defrost system, even in Sabbath mode.	Issue can be avoided with the use of a timer.
The compressor and fans will still function, even in Sabbath mode.	Issue can be avoided with the use of a timer.
The electronic damper which controls the temperature in the fridge will continue to function even in Sabbath mode.	Issue can be avoided with the use of a timer.

RANGES

GE: MODEL JGB750/PGB911

ISSUES:	COMMENTS:
Lights turn on when door is opened.	Bulb should be removed, or left on for Shabbat.
The gas can turn off if door is left open for more than XX seconds, even in Sabbath mode.	Only open door when fire is on, and take food out quickly.
Sound, tones and 12-hour shutoff.	Must be disabled with Sabbath mode.

FRIGIDAIRE: MODEL FGGF3058RF

ISSUES:	COMMENTS:
Lights turn on when door is opened, sounds, tones and 12 hour shutoff.	Must be disabled with Sabbath mode.
The gas can turn off if door is left open for more than XX seconds, even in Sabbath mode.	Only open door when fire is on, and take food out quickly.

WOLF: MODEL GR366

COMMENTS:
This oven uses a mechanical thermostat.
The fires do not turn off when door is opened.

WOLF: MODEL DO-30/M SERIES WALL OVENS

ISSUES:	COMMENTS:
In standard bake mode, if the door is opened, the element will shut off after a 20-second delay. In Sabbath mode, the element will turn off after a 16–32-second delay.	Only open door when element is on, and take food out quickly.

GE: MODEL JGB450

COMMENTS:
This is one of the only self-cleaning ovens on the market that still uses a mechanical thermostat (no computer). Note: the indicator light does not indicate when the fire is on.